

Create-A-Color™ Caulk Mixer Operating Instructions

1. Remove plunger from caulk cartridge as follows:
 - a. Hold cartridge upside down and squeeze center until plunger pushes out from end of cartridge.
 - b. Remove plunger and set it aside.
2. Clean inside of tube at least one inch from end with paint stirrer or dry cloth to allow proper sealing of mixer.
3. With the syringe provided, extract 10mL (2 teaspoons) of latex paint from paint can, and insert paint into the caulk cartridge.
4. Holding the caulk cartridge with the tip down, insert the Create-A-Color™ Caulk Mixer propeller into the cartridge. Slowly push propeller all the way down to the tip of the cartridge.
5. Fasten the pressure cap onto the cartridge and tighten fully by turning tightener ring in a clockwise direction. This provides a tight seal and prevents the contents of the cartridge from coming out.
6. Blend the paint and caulk by holding pressure cap and top of cartridge in one hand, grasping the handle with other hand and pushing the shaft up and down for one to two minutes. Rotate the mixer 180 degrees on each turn.
7. The change in color can be observed through the window. If the contents appear streaked or if untinted caulk adheres to the inside cartridge wall, it does not indicate improper mixing.

IMPORTANT NOTE: UNCURED CAULK COLOR WILL BE SEVERAL SHADES LIGHTER THAN PAINT COLOR. WITHIN 12-24 HOURS OF APPLYING, CAULK WILL DRY AND MATCH THE PAINT COLOR.

8. After mixing, slowly pull the shaft and propeller up as far as possible, and unscrew the mixer to reveal tinted caulk. Carefully tap cartridge once or twice on its tip to pack caulk down.
9. Replace plunger by reversing the removal process. Holding the cartridge with the tip down, squeeze tightly so that caulk rises to the end. Insert plunger into end of cartridge, release pressure and plunger will be drawn into tube. NOTE: Using a toothpick between cartridge and plunger will allow air to escape and facilitate the replacement of plunger.
10. Cut tip of caulk at desired point, puncture inner seal and apply caulk.
11. Clean caulk mixer thoroughly with soap and water after each use. (Follow instructions below).

Create-A-Color™ Caulk Mixer Cleaning Instructions

1. Unscrew handle and tightener ring and set aside.
2. Remove plastic washer, pressure cap and rubber grommet from mixer propeller. Do not remove threaded piston. Removing piston can cause damage to the inner seal.
3. Place all pieces of mixer in a sink or basin and wash thoroughly with soap and water, removing all caulk and paint.
4. Dry all pieces of caulk mixer thoroughly with a clean cloth.
5. Re-attach mixer in reverse order starting with the rubber grommet.

Create-A-Color™ Caulk Mixer Components:



Handle



Tightener Ring



Washer
(PRO Mixer Only)



Pressure Cap



Rubber Grommet



Threaded Piston



Shaft & Propeller

Questions? Please call Red Devil Customer Service at 1-800-4A-DEVIL.